



EMZOOM



Scan QR Code to Get the User Manual



Scan QR Code to Download iOS App



Scan QR Code to Download Android App

Warranty Manual

Foreword

Congratulations on choosing GAC Motor. We sincerely thank you for your purchase.

We are confident it will bring you great driving pleasure. To keep your vehicle in excellent condition, please ensure it is serviced at a GAC Motor authorized service center in accordance with the Periodic Maintenance Schedule outlined in this manual. GAC Motor authorized service centers offer high-quality service at reasonable prices. Our technicians, professionally trained by GAC Motor International, will perform all work in accordance with official service procedures.

This manual is your vehicle's official Warranty and Maintenance Record. Please fill in your user information completely and keep this manual in a safe place. It must be presented when you visit a GAC Motor authorized service center for maintenance or to make a warranty claim.

We wish you a pleasant and enjoyable driving experience in your GAC Motor vehicle.

GAC Motor International

Table of Contents

Warranty Certificate.....	1
1. Vehicle Handover	2
1.1 Pre-Delivery Inspection.....	2
1.2 Vehicle Handover	2
2. Warranty Information	3
2.1 Warranty Information.....	3
2.2 Owner's Responsibilities and Important Notices.....	5
2.3 GAC Motor Authorized Service Center Responsibilities.....	5
3. Maintenance Information.....	6
3.1 First Maintenance Appointment.....	6
3.2 Periodic Maintenance Schedule	7
3.3 Supplementary Maintenance for Severe Driving Conditions	10
3.4 Periodic Maintenance Record Table.....	12
4. Owner Information/Change of Ownership Record	14

Warranty Certificate

User Information	Vehicle Information
Owner Name: _____	Vehicle Model: _____
Owner Type: _____ Industry: _____	Vehicle Identification Number (VIN): _____
Phone Number: _____	Engine Number: _____
Detailed Address: _____	License Plate Number: _____
Postal Code: _____	_____
Purchase Date: Year ___ Month ___ Day ___	_____
Owner Signature: _____	Dealership Name for First Maintenance: _____
Year ___ Month ___ Day ___	(Seal) _____ Dealership Name: _____
	(Seal) _____
	Year ___ Month ___ Day ___ Year ___ Month ___ Day ___
	Warranty Stub: For User Retention

1. Vehicle Handover

1.1 Pre-Delivery Inspection

This vehicle has undergone a Pre-Delivery Inspection (PDI) in accordance with the standards of GAC Motor International. For a detailed list of inspection items, please request the PDI checklist from your authorized dealership.

Inspection Date:

Inspector:

Dealership Seal:

1.2 Vehicle Handover

Before delivery, your GAC Motor authorized service center will conduct a comprehensive inspection and cleaning of your new vehicle. The Pre-Delivery Inspection (PDI) checklist will then be presented to you for your confirmation and signature.

If you are not satisfied with the condition of your vehicle at the time of delivery, please inform the GAC Motor authorized service center and request that the issues be rectified.

Items Delivered with Vehicle (Example: <input checked="" type="checkbox"/> Yes <input checked="" type="checkbox"/> No)	
<input type="checkbox"/> Warranty & Maintenance Manual <input type="checkbox"/> Product Consistency Certificate <input type="checkbox"/> Vehicle Certificate of Conformity <input type="checkbox"/> First key <input type="checkbox"/> Second key <input type="checkbox"/> Spare tire	<input type="checkbox"/> Warning triangle <input type="checkbox"/> Reflective vest <input type="checkbox"/> Tool Kit (see Owner's Manual) <input type="checkbox"/> First Aid Kit* (see Owner's Manual) <input type="checkbox"/> Completed PDI form
<p>*Items marked with an asterisk are included with select vehicle models.</p>	
<p>I have confirmed the above items and received the purchased vehicle.</p>	
<p>Owner / Authorized Person Signature:</p>	

2. Warranty Information

2.1 Warranty Information

Warranty Coverage

This warranty applies to vehicles manufactured by GAC Motor International and sold and serviced through its authorized dealerships.

Warranty Period

The warranty period is calculated from the date the sales invoice is issued or the mileage accumulated, whichever comes first.

Type		Basic Warranty Period (whichever comes first)
Entire Vehicle	Personal/Non-Commercial Use	5 years or 150,000 kilometers, whichever comes first

Wear and Tear Parts Warranty Period

Wear and Tear Parts	Warranty Period (whichever comes first)
Air filter, Oil filter, Fuel filter, Cabin air filter, Bulbs, Spark plugs, Fuses, Tires	3 months or 5,000 kilometers
Drive belts, Brake pads, Clutch discs, Wiper blades, Brake discs	6 months or 5,000 kilometers
Battery	12 months or 15,000 kilometers
Key Fob Battery	6 months or 10,000 kilometers

Warranty Scope

During the warranty period, any issues caused by defects in materials or workmanship will be repaired free of charge by a GAC Motor authorized service center to restore the vehicle to normal operating condition.

Warranty Conditions

1. When determining warranty coverage, GAC Motor authorized service centers will consider the following factors. The following are excluded from GAC Motor warranty coverage:

- a) Vehicle use in countries or regions outside the country or region of sale;
- b) Damage resulting from maintenance, repair, or adjustment performed at a non-authorized service center;
- c) Damage caused by the use of non-genuine GAC Motor parts, lubricants, or fluids;
- d) Vehicle damage caused by negligence, mishandling, driving methods other than those specified in the "Owner's Manual," or exceeding the vehicle's limits (e.g., maximum load, seating capacity, etc.);
- e) Vehicle damage caused by using corrosive or inferior cleaning agents on the vehicle;
- f) Vehicle damage caused by unauthorized modification, installation, adjustment, or disassembly of the vehicle;

- g) Damage caused by misuse, improper handling, negligence, operation by an unqualified or unskilled driver, or use in competitive events (such as racing or rallying);
 - h) Subjective concerns that do not affect vehicle performance: GAC Motor International does not provide warranty for subjective issues that do not affect the quality, function, or performance of the product;
 - i) Any damage caused by improper storage or transportation;
 - j) Damage caused by natural disasters (Acts of God), fire, accidents, theft, or any secondary damage resulting from such events;
 - k) Damage caused by environmental factors beyond normal use for a passenger vehicle, such as industrial fallout, chemical pollutants, bird droppings, salt, or other corrosive substances;
 - l) Corrosion or malfunctions caused by the vehicle being submerged in water;
 - m) Surface corrosion resulting from stone chips, scratches, or other external damage;
 - n) Normal aging or deterioration of paint, headlights, and other items due to natural factors.
2. The warranty does not cover maintenance items such as engine oil, filters, fluids, and auxiliary materials that are necessary for non-warranty repairs.
3. The warranty does not cover the following incidental expenses.
- For example:
- Expenses incurred for communication, mediation, meals, accommodation, etc., due to a malfunction.
 - Any personal injury or property damage.
4. GAC Motor International reserves the right to determine the final repair method and the scope of warranty applicability.

5.. All parts replaced under warranty become the property of GAC Motor International.

6. Use fuels, lubricants, and fluids specified by GAC Motor International.

CAUTION

To avoid warranty liability disputes, please note:

- Failure to perform regular maintenance at a GAC Motor authorized service center as required by the Owner's Manual and this Warranty & Maintenance Manual may jeopardize your warranty coverage.
- If a vehicle malfunctions and the user intentionally destroys the original state of the malfunction, making it unidentifiable, or engages in fraudulent behavior, it may lead to warranty liability disputes.



This manual only shows the base warranty period, please scan the QR code to check the specific warranty date

2.2 Owner's Responsibilities and Important Notices

1. The first maintenance service must be performed at a GAC Motor authorized service center within the first 5,000 kilometers or 3 months, whichever comes first.
2. Please regularly maintain and inspect your vehicle according to the scheduled maintenance table in this manual.
3. To prevent further damage, promptly bring your vehicle to a GAC Motor authorized service center to address any malfunctions. Timely repairs may be covered by warranty.
4. Unsafe changes and modifications to the vehicle are prohibited (e.g., engine modification, vehicle performance changes, changes in light brightness, circuit modifications).

Read the digital Owner's Manual before driving to avoid vehicle damage resulting from incorrect operation or negligence.

CAUTION

- Maintenance and repairs performed at a non-authorized service center may lead to disputes regarding warranty liability.
- Vehicles that do not undergo the first maintenance as required (within 5,000 kilometers or 3 months, whichever comes first) will no longer be eligible for free first maintenance.

Note: Please bring this manual with you when visiting a GAC Motor authorized service center.

2.3 GAC Motor Authorized Service Center Responsibilities

1. At the time of delivery, the dealership is responsible for completing all required information in this manual and explaining the GAC Motor International warranty procedures to the customer.
2. Fully explain the importance of regular vehicle maintenance to the user.
3. The dealership must ensure that all maintenance and repairs, whether covered by warranty or not, are performed according to GAC Motor International's official standards.

4. For damages or defects covered by warranty, provide necessary repairs or solutions to the user.

3. Maintenance Information

3.1 First Maintenance Appointment

The first maintenance must be completed within 5,000 kilometers or 3 months (whichever comes first).

The first maintenance service is provided free of charge by GAC Motor International. Please bring this manual and your digital first-service voucher to a GAC Motor authorized service center to receive this complimentary service. First maintenance items include:

1. Replace:
 - a. Engine oil, drain plug gasket, and oil filter
 - b. Transmission pressure filter element, pressure filter cover oil seal (for Wet Dual-Clutch Transmission)
2. Check and replenish:
 - a. Coolant
 - b. Brake fluid
 - c. Windshield washer fluid
3. Inspection:
 - a. Check battery charge status
 - b. Check parking brake and brake pedal operation
 - c. Inspect drive shaft boots for grease leaks or damage
 - d. Inspect and tighten wheel lug nuts to the specified torque
 - e. Inspect tires/wheels (including spare) for wear; check and adjust tire pressure. Rotate tires if necessary.
 - f. Inspect steering tie rods for play and secure connections; inspect and tighten the bolts at the steering column-to-gear joint to the specified torque.
 - g. Inspect general condition of the vehicle underbody
 - h. Check wiper/washer system operation and adjust nozzles if

necessary

- i. Inspect and tighten chassis bolts and nuts to the specified torque
 - j. Check operation of all interior and exterior lights and electrical devices
 - k. Inspect brake discs and pads for thickness and wear
 - l. Inspect, clean, and lubricate door checks.
4. Clean:
 - a. Air filter element
 5. Self-diagnosis:
 - a. Query fault information using professional diagnostic equipment

3.2 Periodic Maintenance Schedule

Following inspection, perform any necessary actions: add fluid, clean, adjust, lubricate, repair, or replace parts as required.

Perform maintenance at the specified mileage or time intervals (whichever comes first)	km x 1,000	5	15	30	45	60	75	90	105	120	135	150	165	180	195
	Months	3	12	24	36	48	60	72	84	96	108	120	132	144	156
★Replace Engine Oil	•	Every 15,000 km or 12 months thereafter													
Replace engine oil filter	•	Every 15,000 km or 12 months thereafter													
Check spark plugs	No inspection required														
Replace Spark Plugs ^{*1}	Replace every 60,000 km or 48 months thereafter														
Inspect Accessory Drive Belt	Inspect every 15,000 km or 12 months, replace if necessary														
Replace Fuel Filter ²	Every 100,000 km or 60 months														
Replace Charcoal Canister Filter (Other regions)	Every 45,000 km or 36 months														
Replace Charcoal Canister Dust Filter Element (Brazil)	Every 45,000 km or 36 months														
Inspect and clean air filter element	•	No inspection required													
Clean air filter cover, replace air filter element	Inspect every 30,000 km or 24 months, replace if necessary														
Check cooling system for leaks, replenish coolant if necessary	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
★Replace Engine Coolant	Inspect every 45,000 km or 36 months														
★Replace Intercooler Coolant	Inspect every 45,000 km or 36 months														
★Inspect Transmission Fluid (7WDCT)	Maintenance-Free														
★Replace Automatic Transmission Fluid (7WDCT)	50,000 km or 36 months for the first time, and every 60,000 km or 36 months afterwards														
★Replace Pressure Filter Element (7WDCT)	•	50,000 km or 36 months for the first time, and every 60,000 km or 48 months afterwards													
★Replace Brake Fluid	Every 30,000 km or 24 months														

Perform maintenance at the specified mileage or time intervals (whichever comes first)	km x 1,000	5	15	30	45	60	75	90	105	120	135	150	165	180	195
	Months	3	12	24	36	48	60	72	84	96	108	120	132	144	156
Check exhaust emissions (only check for leaks, vehicle annual inspection checks emissions)	Every 15,000 km or 12 months														
Check parking brake, brake pedal (check function and free play of pedal and parking brake)	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Inspect brake discs and pads (check thickness and wear, replace if necessary)* ³	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Inspect wheel lug nuts (check and tighten to specified torque)	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Check tire/wheel (including spare tire) wear, rotate tires if necessary, and correct tire pressure	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Inspect chassis bolts and nuts (check and tighten to specified torque)	•	Every 15,000 km or 12 months thereafter													
Check brake system (check brake fluid lines for leaks, check brake fluid level, replenish if necessary)	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Inspect steering tie rods (check for play and secure connections); inspect bolts at the steering column-to-gear joint (check and tighten to specified torque)	•	Every 15,000 km or 12 months thereafter													
Inspect Vehicle Underside (check fuel lines, brake lines, and underbody for damage; check exhaust system for leaks and security)	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Replace fuel (gas) hoses	Replace hoses every 96 months, or sooner if cracks are found														
Inspect suspension ball joints and dust covers (check for looseness and leaks)	Every 15,000 km or 12 months														
Inspect suspension components (check bushings for aging/damage, bolt/nut torque, and links/rods for deformation/cracks)	Every 15,000 km or 12 months														

Perform maintenance at the specified mileage or time intervals (whichever comes first)	km x 1,000	5	15	30	45	60	75	90	105	120	135	150	165	180	195
	Months	3	12	24	36	48	60	72	84	96	108	120	132	144	156
Inspect wipers/washer system (add washer fluid, check function, adjust nozzles if necessary)		•	•	•	•	•	•	•	•	•	•	•	•	•	•
Clean front windshield cowl drain holes	Every 15,000 km or 12 months														
Clean sunroof drain holes (all four)	Every 15,000 km or 12 months														
Inspect door checks (check function, clean, and lubricate)		•	•	•	•	•	•	•	•	•	•	•	•	•	•
Inspect and lubricate door hinges, locks, latches, and hood/tailgate hinges.	Every 15,000 km or 12 months														
Lubricate electric tailgate drive rod and balance rod ball joints with grease (without disassembling the rods) Grease requirements: Lithium soap-based synthetic hydrocarbon, high viscosity, operating temperature: -30°C~120°C	Every 15,000 km or 12 months														
Inspect rear seat backrest latches (check function, clean, and lubricate)	Every 15,000 km or 12 months														
Check interior and exterior lights and electrical devices		•	•	•	•	•	•	•	•	•	•	•	•	•	•
On-Board Diagnostics (OBD) check (read fault codes with dedicated diagnostic tool)	Perform during any maintenance or repair visit														
Check battery (check battery condition with dedicated tools, ensure secure positive and negative connections, observe voltage)		•	•	•	•	•	•	•	•	•	•	•	•	•	•
Check headlights (check lights, adjust if necessary)	Every 15,000 km or 12 months														
Inspect cabin air filter	Every 15,000 km or 12 months														

Perform maintenance at the specified mileage or time intervals (whichever comes first)	km x 1,000	5	15	30	45	60	75	90	105	120	135	150	165	180	195
	Months	3	12	24	36	48	60	72	84	96	108	120	132	144	156
Replace cabin air filter	Every 15,000 km or 12 months														
Test drive (performance check)	After each maintenance														
Visually inspect the following items															
Inspect drive shaft boots for grease leaks or damage	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•

★: Before each drive, always check the levels of the engine oil, coolant, and brake fluid.

*1: If you frequently use gasoline that contains impurities, the spark plugs may need to be replaced more often. If the engine idle becomes unstable, replace the spark plugs immediately.

*2: If you frequently use gasoline that contains impurities, the fuel filter may need to be replaced more often. If the filter becomes clogged, replace it immediately.

*3: These are considered wear-and-tear parts. We recommend that you inspect them regularly. If you notice any issues, please have your vehicle serviced at a GAC Motor authorized service center.

3.3 Supplementary Maintenance for Severe Driving Conditions

The maintenance schedule is formulated under normal driving conditions. If the vehicle is used under one or more severe conditions, the frequency of certain maintenance items should be increased, or the maintenance interval shortened.

The following are considered severe conditions:

1. Frequent short-distance driving (less than 8 km per trip)
2. Engine continuously idling or stop-and-go driving (e.g., taxis)
3. Driving in muddy or very dusty conditions
4. Frequently towing trailers, or driving with luggage on the roof rack, or driving on mountain roads

5. Long-term driving in cold (below 0°C) or hot (above 35°C) climate conditions
6. Driving more than 20,000 kilometers per year, or frequent high-speed driving, etc.
7. Long-distance driving at low speeds

Item	Severe Conditions	Maintenance Requirements
Replace engine oil and oil filter	1, 2, 3, 5, 7	2,500 kilometers or 3 months
Replace engine coolant	3, 5, 6	40,000 km
Inspect wheel lug nuts	1, 2, 3, 4, 5, 6	5,000 km or 3 months
Check chassis bolts (check and tighten to specified torque)	1, 2, 3, 4, 5, 6	10,000 kilometers or 6 months
Inspect steering tie rods (check for play and secure connections); inspect bolts at the steering column-to-gear joint (check and tighten to specified torque)	1, 2, 3, 4, 5, 6	First 10,000 kilometers or 3 months
Inspect suspension ball joints and dust covers (check for looseness and leaks)	1, 2, 3, 4, 5, 6	thereafter. 10,000 kilometers or 6 months
Inspect suspension components (check bushings for aging/damage, bolt/nut torque, and links/rods for deformation/cracks)	1, 2, 3, 4, 5, 6	10,000 kilometers or 6 months
Replace cabin air filter	3, 5	10,000 km

Note: When the vehicle is operated under severe conditions, the maintenance frequency for the air filter and accessory drive belts should be increased.

3.4 Periodic Maintenance Record Table

5,000 kilometers or 3 months
Mileage: _____
Date: Year__ Month__ Day__
Dealership: _____

15,000 kilometers or 12 months
Mileage: _____
Date: Year__ Month__ Day__
Dealership: _____

30,000 kilometers or 24 months
Mileage: _____
Date: Year__ Month__ Day__
Dealership: _____

45,000 kilometers or 36 months
Mileage: _____
Date: Year__ Month__ Day__
Dealership: _____

60,000 kilometers or 48 months
Mileage: _____
Date: Year__ Month__ Day__
Dealership: _____

75,000 kilometers or 60 months
Mileage: _____
Date: Year__ Month__ Day__
Dealership: _____

90,000 kilometers or 72 months
Mileage: _____
Date: Year__ Month__ Day__
Dealership: _____

105,000 kilometers or 84 months
Mileage: _____
Date: Year__ Month__ Day__
Dealership: _____

120,000 kilometers or 96 months
Mileage: _____ Date: _____
Year__ Month__ Day__
Dealership: _____

135,000 kilometers or 108 months
Mileage: _____ Date: _____
Year__ Month__ Day__
Dealership: _____

150,000 kilometers or 120 months
Mileage: _____ Date: _____
Year__ Month__ Day__
Dealership: _____

165,000 kilometers or 132 months
Mileage: _____ Date: _____
Year__ Month__ Day__
Dealership: _____

180,000 kilometers or 144 months
Mileage: _____
Date: Year__ Month__ Day__
Dealership: _____

195,000 kilometers or 156 months
Mileage: _____
Date: Year__ Month__ Day__
Dealership: _____

4. Owner Information/Change of Ownership Record

Owner Information/Change of Ownership Record Form	
User Information	Vehicle Information
Owner Name: _____	Vehicle Model: _____
Owner Type: Male/Female/Organization _____	Vehicle Identification Number (VIN): _____
Detailed Address: _____	Engine Number: _____
Postal Code: _____	Key Number: _____
Contact Number: _____	If there is a change to the registered owner's information, the GAC Motor authorized service center must complete this form and submit it to GAC Motor International.
Change Date: Year ___ Month ___ Day ___	
Contact Person: _____	
Detailed Address: _____	
Postal Code: _____	Dealership Name (Seal): _____
Contact Number: _____	Person in Charge (Signature): _____
User Signature: _____	Year ___ Month ___ Day ___
Year ___ Month ___ Day ___	



GAC INTERNATIONAL CO., LTD

Address: No. 60 Donglong Road, Panyu District, Guangzhou, P.R. China

Postcode: 511434

www.gacgroup.com